




# STP100/ STP200

0FL-4193-001


Immersion pipe temperature sensor  
Dykrörs temperaturgivare  
Einschraubtemperatursensor  
Sonde de plonge  
Sensor de temperatura entornillado  
Sensore temperatura testa DIN

Instruction  
Montageanvisning  
Bedienungsanleitung  
Instructions d'installation  
Instrucciones de empleo  
Istruzioni per installazioni


1.




2.




3.



4.



5.



6.

