

EBO Modernization Kit for VAV Control Applications

SXWASPRPVMODKIT



SXWASPSBX10002



SXWTBASW110002



SXWTBPSW110001



SXWPS24VX10001



SXWRCF12A10002



SXWRPV4A10001

Before You Begin

Thank you for ordering your EBO Modernization Kit for VAV Control Applications.

This kit is designed to facilitate an initial, simple modernization from Continuum to EcoStruxure™ Building Operation (EBO) software. It is intended to be used in small mechanical rooms requiring VAV control at sites readying to transition from MS/TP to IP. It is not intended to be a one-size-fits-all approach to modernizing an entire trunk. Additional upgrades to controllers and field devices may be required.

Kit Contents

Your kit contains the following hardware:

Part Number	Description
SXWASPSBX10002	SpaceLogic™ AS-P-NLS Secure Boot Automation Server (hardware only, requires AS-P software bundle)
SXWTBASW110002	SpaceLogic Terminal Base for AS-P Controller (base required for each AS-P)
SXWPS24VX10001	SpaceLogic PS-24V Power Supply 24 VAC or 21-30 VDC
SXWTBPSW110001	SpaceLogic Terminal Base for Power Supply (base required for each power supply)
SXWRCF12A10002	SpaceLogic RP-C Controller 12A 8UIOb, 4 solid state DO
SXWRPV4A10001	SpaceLogic RP-V Advanced 4A Controller, Qty 2 4UIOb, no solid-stat relay outputs

Recommended Software

The AS-P Automation Server requires software that must be purchased separately. The recommended software SKU for this kit is listed below.

Part Number	Description
SXWSWXBU0000SA	AS-P Software Bundle Standalone software supporting up to 10 connected products

Additional software licenses may be purchased depending on need and number of connected products.

More information can be found in the *Part Number Summary and Hardware & Software Matrix* available by scanning the QR code below.



Product Documentation

Scan the QR codes below to access the full set of documentation available for each device, including specification sheets, installation guides, declarations of conformity and more.

Part Number	QR Code
SXWASPSBX10002 (SpaceLogic AS-P-NLS Automation Server)	
SXWTBASW110002 (SpaceLogic Terminal Base for AS-P Controller)	
SXWPS24VX10001 (SpaceLogic PS-24V Power Supply)	
SXWTBPSW110001 (SpaceLogic Terminal Base for Power Supply)	
SXWRCF12A10002 (SpaceLogic RP-C Controller)	
SXWRPV4A10001 (SpaceLogic RP-V Advanced 4A Controller)	

To Learn More

Please contact the EcoXpert™ partner or your local Schneider Electric branch for further information.